

# User Manual -TempH

## Single-Use Temperature and Humidity Logger

### Operation Instructions



Press Button  
for 5 seconds

#### 01 Start Recording:

Keep Start button pressed for minimum 5 seconds to start recording, then the OK LED flashes 5 times, and the screen display "▶", "LOG", Temperature and humidity data which indicates a successful starting.



Status Request

#### 02 Recording in Progress:

"OK" or "ALERT" led flash every 30 seconds, and the real time temperature and humidity data display in the screen for every 30 seconds.

**Note:** "OK" flashes means that there is not over temperature/humidity limit during the recording process. "ALERT" flashes means there is over temperature/humidity limit during the recording process



Press button  
for 5 seconds

#### 03 Stop Recording:

Keep STOP button pushed for 5 seconds, the "▶" change to "■", "LOG" icon disappear in the Screen and "ALERT" LED flash 3 times which indicates a successful stopping.



Open this cap

#### 04 Get The Report:

After stopping record, connect the logger to a USB port of the computer, The Report will be generated automatically and can be found in the device's folder.

### Operation indication

#### Start/Stop

Status	Action	LED confirmation	LCD confirmation
Start Logger	5 sec pushing Start button	OK LED flashing 5 times ●●●●●	The screen display from "■" to "▶"
Stop Logger	5 sec pushing Stop button	ALERT LED flashing 3 times ●●●	The screen display from "▶" to "■"

#### Status request by pushing button 1 time

Status	Action	LED confirmation	LCD confirmation
Not Started	Push Start button 1 time	OK LED + ALERT LED Flash one time ●●	LCD display "■"
Recording-OK	Push Stop button 1 time	OK LED Flash one time ●	LCD display Max and Min temperature and humidity data Recorded
Recording-Alarm	Push Stop button 1 time	ALERT LED Flash one time ●●	LCD display Max and Min temperature and humidity data Recorded
Stopped-OK	Push Stop button 1 time	OK LED Flash two times ●●	LCD display last temperature and humidity data
Stopped-Alarm	Push Stop button 1 time	ALERT LED Flash two times ●●●	LCD display last temperature and humidity data